7 inch Wide Screen, TFT Color LCD Type **Graphic Panel + PLC Function Logic Panel LP-S070**

Features

- Supports cost reducing, space saving, easy control by PLC+HMI+I/O module integration
- Adopts 7 inch wide TFT LCD for realizing True Color with 16,777,216 colors
- Analog touch method
- : Free tag arrangement than matrix touch method
- Supports basic I/O of input 16-point, output 16-point
- Supports several device

(auxiliary device 10K Word, data device 10K Word, etc)


- Built-in large capacity memory
 - (program memory: 8,000 step, drawing memory: 16MB)
- Built-in position control function
 - : Provides simultaneous output for max. 100kHz pulse 2-point
- Easy software upgrade available on website (1) LP firmware file

 - (3) SmartStudio (Logic program)
- (5) Language and font, etc
- Data logger function
 - Supports data gathering and backup of controller
- Supports variable image library
- Enables to monitor multi stations and multi channels at the same time
- Supports several interface
 - : Easy to connect various external devices with RS232C 2 ports and RS232C/RS422 multi communication ports

(4) Additional protocol

(2) GP Editor (drawing program)

Enables to extend additional external I/O (when connecting Autonics ARM Series, one communication cable enables to extend 64-point per address, up to 31 address)



- Supports several fonts: Supports window true type and several bitmap font (Selectable)
- Device monitoring function: Enables to monitor/control variable of connected control through communication
- Printer/Barcode reader connection: Enables to print out alarm history, to read barcode



Manual

Visit our webwite (www.autonics.com) to download 'GP Editor user manual' or 'SmartStudio user manual', 'SmartStudio programing manual', 'LP Series command manual', 'LP-S070 user manual', 'GP, LP user manual for communication'.

- GP Editor user manual
 - It describes how to write screen data, and is about related usage of LP-S070 HMI function.
- SmartStudio user manual, SmartStudio programming manual, LP Series command manual It contains install method and usage, commands, etc of SmartStudio.
- GP, LP user manual for communication: It describes connection for external devices such as PLC.
- LP-S070 user manual: It describes general information of the installation and usage of LP-S070 and system Contents.

Ordering Information

Model	Item	Series	Monitor size	Display unit	Color	Power supply	Interface	Module	I/O composition	I/O connector
LP-S070-T9D6-C5T	Logic panel	S series	7 inch	TFT Color LCD	16,777,216 color	24VDC	RS232C, RS422, USB HOST USB DEVICE, Ethernet All-in-		IN: 16-point, OUT: 16-point	Terminal block connector
LP-S070-T9D6-C5R								All-in- one		Ribbon cable connector
LP-S070-T9D7-C5T							RS232C (2), USB HOST			Terminal block connector
LP-S070-T9D7-C5R							USB DEVICE, Ethernet			Ribbon cable connector



7 inch TFT Color LCD

R-26 **Autonics**

Specifications

Model		LP-S070-T9D6-C5T	LP-S070-T9D6-C5R	LP-S070-T9D7-C5T	LP-S070-T9D7-C5R				
I/O connector type		Terminal block connector	Ribbon cable connector	Terminal block connector	Ribbon cable connector				
Power supply		24VDC							
Allowa	ible voltage range	90 to 110% of power supply							
Power	consumption	Max. 7.2W							
	LCD type	7 inch TFT Color LCD							
ng «	Resolution	800×480 dots							
awi	Display area	152.4mm×94.44mm							
c dr	Color	16,777,216 color							
Graphic drawing performance	LCD view angle	Within each 50°/ 60°/ 65°/	Within each 50°/ 60°/ 65°/ 65° of top/bottom/left/right						
Gra	Backlight	White LED							
	Brightness	Adjustable by software							
3	Language ^{×1}	English, Korean							
Graphic drawing performance	• Vector font • 6×8, 8×8 ASCII character, high definition numbers Text • 8×16 ASCII characters, 16×16 character by each country (1 to 8 times bigger for width, 0.5 to 5 times bigger for height)			ry					
phic irfor	Graphic drawing memory	16MB							
Gra _l	Number of user screen	500 pages							
)	Touch switch	Analog touch							
	Command	Basic command: 28, application command: 233							
ġ.	Program capacity	8K step							
Control performance	Processing time	Average: Approx. 2us/basic command, application command							
Control	I/O control type	Batch processing							
Co	Computer control mode	Repeated-doubling method, interrupt processing							
۵	Device range	*Refer to LP-S070 user manual							
	Special function	Positioning function *Refer to LP-S070 user manual							
Serial	interface	Asynchronous method: Each port of RS232C, RS422							
		Each port of RS232C, RS422 Two ports of RS232C							
USB interface		Each of USB Host, USB Device (Version 1.1)							
Ethernet interface		IEEE802.3 (U), 10/100Base-T							
	ime controller	RTC embedded							
	y life cycle	Approx. 3 years at 25°C							
	ted resistance	Min. 100M Ω (at 500VDC megger)							
Groun		3rd grounding (max. 100Ω)							
	immunity	The squre wave noise (pulse width 1µs) by the noise simulator with ± 0.5kV							
	standing voltage 500VAC 50/60Hz for a minute 0.75mm amplitude at frequency of 10 to 55Hz (for 1 min.) in each X, Y, Z direction for 1 hour								
Vibra -tion	Mechanical				·				
-11011	Malfunction	0.5mm amplitude at frequency of 10 to 55Hz (for 1 min.) in each X, Y, Z direction for 10 min.							
Shock	Mechnical	300m/s² (approx. 30G) in each X, Y, Z direction for 3 times							
	Malfunction	100m/s² (approx. 10G) in each X, Y, Z direction for 3 times							
Environment	-								
	material management of the control								
Protec	· · · · · · · · · · · · · · · · · · ·	IP65F (for front panel)	ny (included)						
Acces		Fixing bracket: 4EA, Batte	ry (included)						
Appro									
Unit w		Approx. 540g	anment registance is as	ted at no freezing or cor	denoction				

*1: Language could be added in the future. *Environment resistance is rated at no freezing or condensation.

■ Input/Output Performance

Input performance		Output performance		
Input point	16-point	Output point	16-point	
Insulation method	Photo coupler insulation	Insulation method	Photo coupler insulation	
Voltage range	19.2 to 28.8VDC	Voltage range	19.2 to 28.8VDC	
Rated input voltage	24VDC	Rated input voltage	24VDC	
Input resistance	Contact X0 to X5: Approx. 10mA Contact X6 to XF: Approx. 4mA	Max. load current	0.1A/1point, 1.6A/1COM	
Input resistance	Contact X0 to X5: 2.2kΩ, Contact X6 to XF: 5.6kΩ	Max. voltage falling when ON	Max. 0.2VDC	
Response time	1ms	Response time	1ms	
Common method	16-point/1COM	Common method	16-point/1COM	
Acceptable wire	0.3 to 0.7mm ²	Acceptable wire	0.3 to 0.7mm ²	

Autonics R-27

(A) Photoelectric Sensors

(B) Fiber Optic

(C) Door/Area Sensors

(D) Proximity Sensors

Sensors

(F) Rotary Encoders

Connectors/ Sockets

Temperature Controllers

(I) SSRs / Power Controllers

(J) Counters

(K) Timers

Panel Meters

(M) Tacho / Speed / Pulse Meters

(N) Display Units

(O) Sensor Controllers

(P) Switching Mode Power Supplies

(Q) Stepper Motors & Drivers & Controllers

> R) Fraphic/ Jogic Panels

Field Network Devices

(T) Software


■ Functional Description

Fig	jure display	Line, rectangle, circle, text, bitmap				
	Numeral display	Displays the designated device as numerical value. (decimal, hexadecimal, octal, binary, real number)				
	ASCII display	Displays the designated device value as ASCII character.				
	Time display	Displays current time or date.				
	Alarm history	Registers alarm history.				
	Alarm list	Displays generated (not backed up) alarm.				
	Comment display	Displays the designated comment as device status or value.				
	Lamp	Displays lamp as device status.				
gs	Part display	Displays the designated parts as device status and value.				
Tags	Line graph	Displays several device values with a graph of broken line.				
	Trend graph	Displays change of device value for time with a graph of broken line.				
	Bar graph	Displays a device value with a bar graph.				
	Statistic graph	Displays a ratio of several device values with pie graph.				
	Panel meter	Displays a device value as panel meter.				
	Touch key	Screen is switched, word/bit device values are set when it touched.				
	Numeral input	Configures user input value in device.				
	ASCII input	Configures user input ASCII code value in device.				
Sy	stem information function	Monitors/Controls LP operation from PLC.				
Re	cipe function	Reads/Writes several PLC device collectively.				
Se	curity function	Only acceptable user can observe/operate important data.				
Ва	rcode read function	Connects barcode reader, read barcode.				
Flo	ating alarm function	Warning message is floated when alarm is generated.				
Tir	ne operation	Specific bit device is ON/OFF for designated day and time.				
Ov	erlap window	Available to form dynamically overlapping another base screen on the base one.				

Dimensions (unit: mm) • Panel cut-out Min. 240 185 Max. 4-R3 186+1 126 10 175 ※ Panel thickness : Max. 4mm 194 6.5 28.5 • Fixing bracket M4 BOLT 125 146

R-28 Autonics


Unit Description




- Ethernet port: For connecting LAN cable and hub, use direct cable, and for connecting PC directly, use cross cable.
- USB Device: It is used to upload and download project (It is required to install USB driver on PC), and when connecting to PC, it can be used as a USB memory (PC recognizes it as a removable disk).
- USB Host: It used to manage data and upgrade firmware.
- RS232C, RS422 port: For more information, refer to page R-32 and ' Serial Interface' of GP/LP Common Features.

Installation

- 1. Set LP-S070 in panel.
- 2. Set fixing brackets in 4 slots (2 slots is in upper side, 2 slots is in lower side).



3. Tighten fixing bracket with M4 screw driver and tightening torque is 0.3 to 0.5N m.



(A) Photoelectric Sensors

(B) Fiber Optic

> (C) Door/Area Sensors

(D) Proximity Sensors

(E) Pressure Sensors

(F) Rotary Encoders

(G) Connectors/ Sockets

(H) Temperature Controllers

(I) SSRs / Power Controllers

(J) Counters

(K)

L) anel

(M) Tacho / Speed / Pulse

(N) Display Units

(O) Sensor Controllers

(P) Switching Mode Power Supplies

(Q) Stepper Motors & Drivers & Controllers

(R) Graphic/ Logic Panels

(S) Field Network Devices


> T) Software

Autonics R-29


■ Input-Output Wiring

© LP-S070-T9D6 (7)-C5R

• Input wiring (source type input module)




• Output wiring (sink type output module)




© LP-S070-T9D6 (7)-C5T

• Input wiring (source type input module)



• Output wiring (sink type output module)



XCheck the pin number of the case before wiring.

■ Sold Separately

O I/O terminal block and I/O cable

Suitable I/O terminal block	INPUT/OUTPUT	Suitable I/O cable		
AFS-H20	INPUT	CJ-HPHP20-V1N□-1ANR		
(Interface terminal block)	OUTPUT			
ABS-H16PA (TN)-NN (Relay terminal block)	OUTPUT	CJ-HPHP20-V1N□-1APR		
AFE4-H20-16LF	INPUT	CJ-HPHP20-V1N□-1BNR		
(Sensor connector terminal block)	OUTPUT	CJ-HPHP20-V1N□-1APR		
	l 	CJ-HP20-VP□-R (OPEN type cable)		
		CJ-HP20-VP□-L (OPEN type cable)		

XIt is only for ribbon cable connector (hirose connector) type.

○ Communication cable (RS232C, RS422 port)

For serial connectable cable to connect PLC and external devices, refer to page R-32 for "GP/LP Communication Cables".

R-30 Autonics

X"□" is cable length. (Basic specification 010: 1m, 020: 2m, the others are option)

XFor more information, refer to "Control switches & Terminal Blocks/Cables Catalog".